












MTSL\_H270\_1522231789\_B




MTSL\_H270\_1522231789\_B N

NR	ELEMENT	MTSL_H270_1522231789_B N
1		
2		3
3		1
4		
5		1
6		


NR	ELEMENT	MTSL_H270_1522231789_B N
7		1
8		1
9		1
10		1
11		4
12		1

NR	ELEMENT	MTSL_H270_1522231789_B N



MTSL\_H270\_1522231789\_B N

Nr	Element			Σ
10		DIN 9021	6x18	304
15		ISO 7380	M6x30	144
16		-	K1_d21_B	160
17		-	Z1_d21_B	160
18		DIN 985	M6 (OC)	144
58		-	LOCTITE	1
472		DIN 933	M6x25 (OC)	16
45		ISO 7380	M8x30	3
21		DIN 125	8x16	6
43		DIN 1587	M8	3





1

MTSL\_H270\_1522231789\_B N



INST\_MTS\_2  
INST\_MTS\_3  
INST\_MTS\_4  
INST\_MTS\_5  
INST\_MTS\_11



[buglo.pl/mts-manual](http://buglo.pl/mts-manual)

MANUAL